


# AVATAR GT KIT

## QUICKSTART GUIDE

V1.1

### Introduction



- 1、Camera
- 2、Fan
- 3、Serial Port Pad
- 4、Power Port
- 5、Link Button
- 6、Micro SD Card Slot
- 7、VTX LED
- 8、Antenna

### Connection



- Power consumption: 12V@1.5A. Please consider the power supply capability of the power supply.
- VTX generates a lot of heat when working, so please pay attention to airflow for heat dissipation

### Linking

- Connect the VTX and the power of the goggles.
- Short press the VTX and goggles linking buttons respectively, when the VTX enters the pairing state The VTX LED turns red, and the goggles end is a DI... DI... DI...
- After the link is successful, the indicator light on the VTX LED turns solid green, the beeping sound on the goggles stops and the screen is displayed.

### Upgrade

Please go to the official website to download the upgrade firmware, Avatar\_Sky\_X.X.X.img is the VTX file, be careful not to change the file name.


- Copy the upgrade file to the VTX Micro SD card directory, connect the power supply and wait for the device to start up (if there are old firmware files, please delete them).
- Press and hold the VTX linking button for 8 seconds, and release the button after the indicator light goes out. At this time, the VTX will automatically restart and enter the upgrade state, and the indicator light will change from blinking red to solid red and then turn off. The upgrade time is about 20 seconds, please do not power off during the upgrade process! (If the VTX continues to light up red, it means that the firmware cannot be detected or the firmware is wrong, please check the firmware file)
- After the upgrade is successful, the VTX indicator turns green and blinks.

\*The Avatar GT TF card slot does not have a rebound function. Please stick the PVC sticker to the TF card before inserting it.

### UART

The UART function enables the VTX communicate with the flight controller, allowing the VTX obtain the flight controller information. Take Betaflight Configurator as an example to introduce the UART setting method.

- Solder the white and gray wires of the 4 pin cable to the flight controller (refer to the Connection page).




- Connect the flight controller to the Betaflight Configurator, and open the corresponding UART port (Take UART1 as an example in the figure) Check the MSP switch and click Save.




- Open the CLI command line and enter the content in red font  
"set osd\_displayport\_device = MSP"  
"set displayport\_msp\_serial = Y" (Where Y is one less than the number of the serial port. e.g. Y = 2 for serial 3)  
"save"

### Betaflight 4.4 or above version settings:



- Open the corresponding uart port (Take uart1 as an example in the figure) Check the MSP switch and click Save, Check the VTX (MSP+Displayport).



- Open the CLI command line and enter the content in red font,  
"set osd\_displayport\_device = MSP"  
"set vcd\_video\_system = HD"  
"save"

### Status indication

| Goggles Buzzer Status                            |                             |
|--|-----------------------------|
| Link state                                       | DI...DI...DI...             |
| upgrade firmware                                 | DI.....DI.....DI..... DI—   |
| Upgrade failed                                   | DI..DI..DI..                |
| VTX Indicator Status                             |                             |
| Link state                                       | Steady red light            |
| upgrade firmware                                 | Red light rapidly flashes   |
| Wireless connection, image output is normal      | Steady green light          |
| Wireless not connected                           | green light rapidly flashes |
| Wireless connection is normal, image is abnormal | green light slowly flashes  |

### Precautions

- Before powering on, please install all antennas to avoid damage to components.
- When the standby mode is turned on, the power is limited to 10mW. Before taking off, you need to unlock the flight control or turn off the standby mode.
- If you use it with other 5.8GHz devices at the same time, please choose a different channel.
- If you use the Gyroflow function of the camera, please provide shock absorption for the fixed deck of the camera to avoid the failure of the anti-shake.

### VTX Specification

|                          |  |
|--------------------------|--|
| Name                     | Avatar GT KIT  |
| Communication Frequency  | 5.725–5.850 GHz  |
| Transmitter Power (EIRP) | MAX: 33dBm; FCC: <30dBm; CE: <14dBm; SRRC: <20dBm; MIC: <25dBm |
| I/O Interface            | JST1.0*4(power cable); micro sd card slot                      |
| Mounting Holes           | 25.5*25.5mm; 20*20mm   |
| Dimensions               | 33.8*33.8*23.4mm   |
| SD card                  | Support 256G   |
| Recording                | 1080p/720p   |
| Weight                   | 29.7g  |
| Operating Temperature    | -10-40°C   |
| Channels                 | 8  |
| Wide Power Input         | 11.1V-25.2V  |
| Supported FC System      | Betaflight; Inav; Fettec; Kiss; ArduPilot                      |
| OSD                      | Canvas mode  |
| Latency                  | Average delay 22ms   |
| Antenna                  | 2(IPEX)  |

### Camera parameters

|                  |  |
|------------------|--|
| Name             | Avatar pro camera                                  |
| Image Sensor     | 1/1.8-Inch sony starvis2 sensor                    |
| Resolution       | 1080P/100fps; 1080P/60fps; 720P/100fps; 720P/60fps |
| Ratio            | 4/3 16/9   |
| Lens             | 8Mp  |
| FOV              | 160°   |
| Aperture         | F1.6   |
| Shutter          | Rolling shutter                                    |
| Weight           | 9.5g   |
| Dimensions       | 19*19*24mm   |
| Min.Illumination | 0.0001Lux  |
| Coaxial Cable    | 140mm  |

### VTX Antenna

|                 |                              |
|-----------------|------------------------------|
| Name            | Avatar V2 antenna            |
| Polarization    | LHCP                         |
| Frequency range | 5600MHz-6000MHz              |
| Average Gain    | 1.9dBi                       |
| VSWR            | ≤1.5                         |
| Interface       | IPEX-1                       |
| Dimension       | D15mm X 45mm (without cable) |
| Weight          | 2g                           |

CADDXFPV Support  
email: support@caddxfpv.com


This content is subject to change.Download the latest version from <https://www.caddxfpv.com>

# AVATAR GT KIT

## 快速入门指南


V1.1

### 简介



- 1、相机
- 2、风扇
- 3、串口焊盘
- 4、电源端口
- 5、对频按钮
- 6、Micro SD 卡槽
- 7、VTX 指示灯
- 8、天线

### 接线



- ⚠ 功耗参考: 12V@1.5A, 接线时请考虑电源供电能力
- 产品工作时发热量大, 请注意气流散热

### 对频

1. 连接 Avatar GT 和眼镜端电源。
2. 分别短按 Avatar GT 和眼镜端对频按钮, Avatar GT 进入配对状态后 VTX LED 变为红灯常亮, 眼镜端蜂鸣器为 DI...DI...DI...
3. 连接成功后, VTX LED 指示灯呈绿色常亮, 眼镜端蜂鸣声停止并显示图像。

### 升级

请到官网下载最新升级固件, Avatar\_Sky\_X.X.X.img 对应 Avatar GT 升级固件, 注意请勿修改文件名。

1. 将升级文件拷贝到 Avatar GT 的 Micro SD 卡根目录下, 连接电源等待设备开机 (如果有旧固件文件请删除)。
2. 长按 Avatar GT 对频按钮 8 秒, 等指示灯熄灭后松开按钮, Avatar GT 自动重启进入升级状态, 指示灯从红色闪烁变为红色常亮然后再熄灭。升级时间大约为 20 秒, 升级过程中请勿断电! (如 Avatar GT 持续常亮红灯, 表示检测不到固件或固件错误, 请检查固件文件)
3. 升级成功后, Avatar GT 指示灯变为绿色闪烁。

\*Avatar GT Micro SD 卡槽没有回弹功能, 请先将 PVC 贴纸粘贴到 Micro SD 卡再插入


### UART

UART 功能可以使图传与飞控进行通信, 获取飞控 OSD 等信息。以 Betaflight Configurator 为例介绍 UART 设置方法。

1. 将 4Pin 电源线白线和灰线焊接到飞控 Uart 串口 (参考连接页面), 这里以 Uart 1 串口为例。




2. 将飞控连接到 Betaflight Configurator, 打开对应的 UART 接口, 勾选 MSP 开关, 点击保存。




3. 打开 CLI 命令行, 输入红色字体内容, "set osd\_displayport\_device = MSP", "set displayport\_msp\_serial = Y" (其中 Y 比使用串口数小一位, 例如 Y = 0 对应 Uart 1, Y = 2 对应 Uart 3 以此类推), "save"

### Betaflight 4.4 或以上版本设置:



1. 打开对应的 UART 接口, 勾选 MSP 开关, 勾选 VTX (MSP+Displayport)。



3. 打开 CLI 命令行, 输入红色字体内容, "set osd\_displayport\_device = MSP", "set vcd\_video\_system = HD", "save"

### 状态指示

| 眼镜端蜂鸣器状态     |                        |
|--------------|------------------------|
| 对频状态         | 滴...滴...滴...           |
| 升级固件         | 滴.....滴.....滴..... 滴—— |
| 升级失败         | 滴..滴..滴..              |
| VTX 指示灯状态    |                        |
| 对频状态         | 红灯常亮                   |
| 升级固件         | 红灯快速闪烁                 |
| 无线连接, 图像输出正常 | 绿灯常亮                   |
| 无线未连接        | 绿灯快速闪烁                 |
| 无线连接正常, 图像异常 | 绿灯慢闪                   |

### 注意事项

- 1、通电前请安装好所有天线, 避免元器件损坏。
- 2、待机模式开启时功率受限 10mW, 起飞前需解锁飞控或关闭待机模式。
- 3、如果您同时与其他 5.8GHz 设备一起使用, 请选择不同频道。
- 4、如果您使用相机陀螺仪功能, 请给相机固定平台做减震, 避免防抖失效。

### VTX 规格

|             |  |
|-------------|--|
| 名称          | Avatar GT KIT  |
| 通信频率        | 5.725-5.850 GHz  |
| 发射功率 (EIRP) | MAX: 33dBm; FCC: <30dBm; CE: <14dBm; SRRC: <20dBm; MIC: <25dBm |
| 接口          | JST1.0*4(电源线); Micro SD 卡槽                                     |
| 安装孔距        | 25.5*25.5mm; 20*20mm   |
| 外形尺寸        | 33.8*33.8*23.4mm   |
| SD 卡槽       | 支持 256G  |
| 录制规格        | 1080p/720p   |
| 重量          | 29.7g  |
| 工作环境温度      | -10~40°C   |
| 频点数量        | 8  |
| 宽电源输入       | 11.1V-25.2V  |
| 支持飞控系统      | Betaflight; Inav; Fettec; Kiss; ArduPilot                      |
| OSD         | Canvas mode  |
| 端到端延时       | 平均延时 22ms  |
| 天线          | 2(IPEX)  |

### 相机规格

|       |  |
|-------|--|
| 名称    | Avatar pro camera                                  |
| 图像传感器 | 1/1.8-Inch sony starvis2 sensor                    |
| 分辨率   | 1080P/100fps; 1080P/60fps; 720P/100fps; 720P/60fps |
| 比例    | 4/3 16/9   |
| 镜头    | 8Mp  |
| FOV   | 160°   |
| 光圈    | F1.6   |
| 快门    | 卷帘快门   |
| 重量    | 9.5g   |
| 外形尺寸  | 19*19*24mm   |
| 最低照度  | 0.0001Lux  |
| 同轴线   | 140mm  |

### VTX 天线

|      |                    |
|------|--------------------|
| 名称   | Avatar V2 antenna  |
| 极化方向 | LHCP               |
| 工作带宽 | 5600MHz-6000MHz    |
| 平均增益 | 1.9dBi             |
| 输入阻抗 | 50Ω                |
| 驻波比  | <1.5               |
| 接口   | IPEX-1             |
| 外形尺寸 | D15mm X 45mm (不含线) |
| 重量   | 2g                 |

CADDXFPV 技术支持

email: support@caddxfpv.com

此内容可能会修改, 从以下位置下载最新版本

https://www.caddxfpv.com