

Reaper Infinity 5W VTX



规格:

1. 尺寸: 41*20*17mm
2. 接口: SMA
3. 显示灯: 3颗LED
4. 重量: 58g
5. 功率: 50mW/500mW/1000mW/2500mW/5000mW
6. 输入: 9~36V
7. 输出: 5V
8. 通道: 40CH
9. 遥控器协议: Tramp

1. LED灯说明

LED	说明
红灯	功率
绿灯	通道
蓝灯	频段

2. 按键操作方法

- 短按, 进入通道设置, 短按设置不同通道;
- 长按3秒, 进入频段设置, 短按设置不同频段;
- 继续长按3秒, 进入功率设置, 短按设置不同功率。

3. 频率表

Channel	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Band A	5865	5845	5825	5805	5785	5765	5745	5725
Band B	5733	5752	5771	5790	5809	5828	5847	5866
Band E	5705	5685	5665	5645	5685	5905	5925	5945
Band F	5740	5760	5780	5800	5820	5840	5860	5880
Race Band	5658	5695	5732	5769	5806	5843	5880	5917
Power (mW)	PIT	50	500	1W	2.5W	5W		

4. 如何解锁图传功率和频率

长按按键, 红灯亮, 灭, 再次亮起, 解锁, 解锁状态下, 红灯闪烁, 未解锁状态下, 红灯常亮。

5. PIT模式

双击按键进入PIT模式, 红灯灭表示进入了PIT模式, 次模式下, 图传输出功率极低。

Reaper Infinity 5W VTX



Spec:

1. Size: 41*20*17mm
2. Connector: SMA
3. Display: 3LED
4. Weight: 58g
5. Power: 50mW/500mW/1000mW/2500mW/5000mW
6. Input: 9~36V
7. Output: 5V
8. Channel: 40CH
9. Protocol: Tramp

1. LED

LED	Description
Red	Power
Green	Channel
Blue	Band

2. Button Operation

Channel select mode:

Short click, enter CHANNEL setup, only green light is on and flash, select channel by short presses.

Band select mode:

Continue to press the button for 3s, enter BAND setup, blue LED on and flash, select band by short click.

Power select mode:

Continue to press the button for 3s, enter POWER setup, RED LED is on and flash, select power by simple short presses.

3. Frequency Table

Channel	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Band A	5865	5845	5825	5805	5785	5765	5745	5725
Band B	5733	5752	5771	5790	5809	5828	5847	5866
Band E	5705	5685	5665	5645	5885	5905	5925	5945
Band F	5740	5760	5780	5800	5820	5840	5860	5880
Race Band	5658	5695	5732	5769	5806	5843	5880	5917
Power (mW)	PIT	50	500	1W	2.5W	5W		

4. Unlock the frequencies and power levels

Long press the "KEY" button until the Red LED (PWR) is constant on, off, then on again, release the button unlock the all frequencies and power levels, flashed Red LED means in unlocked status, constant Red LED means in locked status.

5. PIT Mode On/Off

Double-click the "KEY" button to turn on/off the PIT Mode. Red LED (PWR) off means PIT mode on; Red LED (PWR) on means PIT mode off. In PIT mode, VTx output extreme low power.