



II. Buttons and LED indicator lights



- Channel no. indicator: Red light LED (band A)
 Channel no. indicator: Blue light LED (band B)
 Power ON/OFF indicator: Green light LED
- Frequency channel & band selection key
- 5 Tx Power ON/OFF key
- 6 1.0 6P wiring socket
- MMCX antenna connector

III. Wiring method



7-36V IN: 2-8s, VTX positive input GND: VTX negative RX-IRC: IRC Tramp signal input 5V-OUT: 5V power supply output

IV. Key control and LED indicators definition:

1. Key 4 is the frequency channel & band selection key. Press key 4 for a short period of time will switch to the next frequency channel. Depends on the frequency plan or band we are using, the corresponding red LED ① (band A) or blue LED 2 (band B) will flash 1, 2,3,4,5,6,7 or 8 times for channel

Press key 4 for a period longer than 3S will switch to another channel frequency plan or band. For example, if now we are in channel no. 3 of band A, the red LED ① will flash 3 times. If we press key 4 for more than 3S and release, the red LED 1 will be turned off and blue LED 2 will flash 3 times which means we are now in channel no. 3 of band B.

Frequency channel or band selection is cyclic. Please refer to the following table for details:

Channel	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Red LED (Band A)	Flash once	Flash twice					Flash for 7 times	
Blue LED (Band B)	Flash	Flash	Flash	Flash	Flash	Flash	Flash	Flash

2. Key 5 is the Tx power ON/OFF control key. Press it for a short period of time to turn the output power ON or OFF. If the key is pressed and held for 3 seconds, the module will enter pit mode and all the LEDs will be turned on simultaneously. See the following table for details:

1. Short press key	L. Short press key ⑤ to toggle the output power ON/OFF.						
2. Long press the key to enter Pit mode.							
Tx output power	Tx output power	Pit mode					
ON	OFF	Pit mode					
Green LED ③ is	Green LED ③ is	All 3 LEDs will be turned					
turned on	turned off	on simultaneously					

V. Table of Corresponding Channel Frequency Parameters

Channel	Channel Frequency Table (in MHz)							
Channel	CH1	CH2	СНЗ	CH4	CH5	СН6	CH7	CH8
Band A	3320	3345	3370	3395	3420	3445	3470	3495
Band B	3310	3330	3355	3380	3405	3430	3455	3480

展开尺寸100x280mm,折后尺寸: 70x100mm